

AIR SAFE

**Receiver Hitch
Installation/Operation
Instructions
CLASS I-II
1-866-41 HITCH**

AIR SAFE

AIR SAFE™

AIR SAFE™

The following instructions should be used to mount **AIRSAFE™ AIR RIDE HITCH®** only. Please **read and follow instructions before installation.** Failure to follow instructions may void the manufacturer's warranty. Max TW 300lbs/Max GTW 3,000lbs

1. (A) **CLASS I-II HITCH-** The Hitch's receiver tube plate has four 1/2" drilled and tapped holes to install the hitch's receiver tube. The receiver tube may be mounted in two positions to obtain different hitch heights.
 2. Mount the ball on the ball mount platform. The ball must have 1" shaft to fit in the hole provided.
 3. Slide the hitch's 1 1/4" receiver tube into the vehicles 1 1/4" receiver tube. Install pin and pin keeper (neither provided) into place
 4. Inflate air bag. Align trailer to hitch ball and secure trailer hitch into position. Inflate or deflate the air spring until the ball mount is level/horizontal. Enough air should be placed in the air springs to keep the ball mount level.
 5. Attach safety chains, hook up brake lines, plug up lights and take care of any other safety items.
 6. To unhitch the trailer, use trailer jack to raise tongue and unhitch trailer.**CAUTION: Do not over- inflate the air springs. Never exceed 100 PSI.**

